



FRONT: 0.78m
SIDE: 0.78m
HEIGHT: 2.035m



Quality
Endorsed
Company
ISO9002
LIC NO. 155
STANDARDS AUSTRALIA



We thank you for choosing an Australian Made Shed. For further assistance please visit our detailed instructional video library at <http://www.absco.com.au/videos.php>

At ABSCO Industries we are always looking to be number ONE, so please let us know what you think of our instructions. Feedback makes us better.
feedback@absco.com.au.

GENERAL INSTRUCTIONS

- Before commencing any assembly, read through these instructions in detail to gain a thorough understanding of assembly methods and associated details.
- Unpack the carton and carefully identify and check off all the parts against the parts described and illustrated on pages three and four.

SITE PREPARATION

- The site for the shed must be level.
- It is recommended that the shed be set on a 100mm concrete slab and anchored down appropriately (refer page 16 for details).
- Anchor sets are not supplied as standard items with this product.

TOOLS REQUIRED



3mm
4mm


















OPTIONAL

A NOTE ON SAFETY












- Some parts may have sharp edges. It is advisable to wear gloves when handling these items and safety glasses if drilling holes. Sensible shoes are highly recommended.
- Do not erect your shed in windy conditions, ensure that the shed is securely anchored to a solid foundation immediately after construction is completed.
- It is highly recommended to erect the shed with two or more people.




COMPONENTS PACKING LIST - CHECK OFF ALL COMPONENTS

QTY	COMPONENT DESCRIPTION	PART No.	CHECK	QTY	COMPONENT DESCRIPTION	PART No.	CHECK
2	 STEEL SHEET 2035mm X 773mm	H30		2	 CHANNEL L = 773mm	58C	
1	 STEEL SHEET 852mm X 773mm	43T		1	 CHANNEL L = 720mm	54G	
1	 STEEL SHEET 2035mm X 773mm	H30F		2	 CHANNEL L = 773mm	81J	
1	 DOOR SHEET 1974mm X 711mm	H37A		2	 CHANNEL L = 2035mm	H80A	
2	 CHANNEL L = 766mm	54H		1	 CHANNEL L = 1974mm	HC2	
2	 CHANNEL L = 773mm	54F		2	 CHANNEL L = 712mm	58M	
2	 CHANNEL L = 773mm	61E		1	 JAMB L= 2035mm	HJ1	
				1	 JAMB L= 2035mm	HJ2	

COMPONENTS PACKING LIST - (CONT.) CHECK OFF ALL COMPONENTS


QTY	COMPONENT DESCRIPTION	PART No.	CHECK	QTY	COMPONENT DESCRIPTION	PART No.	CHECK
1	 JAMB L= 720mm	91D		2	 LIP TRIM L= 852mm	88L	
1	 DOOR TRIM SIDE CHANNEL WITH HINGES FITTED L = 1974mm	HC1		2	 JAMB L= 1080mm	91A	
CONTENTS OF FITTINGS PACKET							
120	 SELF TAPPING SCREWS 10mm			1	 DOOR PADBOLT	22A	
6	 4mm CSK SCREW & NUT SECURE HINGES TO DOOR			1	 DOOR PADBOLT HASP		
12	 SELF TAPPING SCREWS 20mm REFER TO PAGE 15			6	 3mm POP RIVETS SECURE HINGES TO DOOR (ALTERNATIVE FIXING METHOD)		
1	ASSEMBLY INSTRUCTIONS			1	 DOOR STRAP L: 165mm	12A	

VIEW OF ROOF COMPONENTS






61E






VIEW OF WALL COMPONENTS

ABSCO ASSEMBLY INTRODUCTION

The snap-tite assembly system locks most perimeter channels to all roof and wall sheets without the need for tools and fasteners. The front door frame and door assembly will require 3mm holes to be drilled where necessary.




To pre-assemble the four wall panels and two roof panels, the perimeter channels are secured to the top and bottom of each panel using the snap-tite system, as detailed on the following pages wherever you see the symbol.




After joining sheets together, position channel over one end of the sheets, gently tapping it over the snap-tite lugs, working along the sheets to the other end.

Position sheets on timbers, trestles or partly over edge of concrete slab.



Each perimeter channel must finish flush with the edges of the sheets. The snap-tite system allows adjustment for this process by simply tapping the channel along the sheets until each end is neatly flush.

FASTENING SYMBOLS

 Join components together with one screw at this location only, as some channel sections have extra holes that are not required for this model of garden shed


 3mm POP RIVETS

 4mm NUT & BOLT SET

 Do not join components together at this location yet, as the screw may obstruct further assembly of other components


SIDE PANEL ASSEMBLY

LEFT SIDE PANEL




SIDE PANEL ASSEMBLY






RIGHT SIDE PANEL




REAR PANEL ASSEMBLY



ROOF PANEL ASSEMBLY




FRONT FRAME ASSEMBLY



DOOR PANEL ASSEMBLY

NOTE: THIS SHEET (H37A) IS 711mm WIDE BY 1974mm HIGH



FRONT PANEL AND DOOR CONNECTION
ASSEMBLY PHOTOS

CORNER DOOR JAMB ASSEMBLY



DOOR CONNECTION & JAMB ASSEMBLY



PADBOLT & HASP CONNECTION




PADBOLT TO DOOR CONNECTION



NOTE: PLEASE REFER TO
THE FOLLOWING PAGES
FOR FURTHER DETAIL


PANEL CONSTRUCTION

NOTE: Take care to ensure that both front and rear wall panels are not positioned upside down. The top channel of each panel is pre-punched for attaching roof sheets. The base channels are not pre-punched.




ROOF CONSTRUCTION AND ANCHORING OF SHED


NOTE: IT IS IMPORTANT TO COMPLETE THE STEPS ON THIS PAGE BEFORE PROGRESSING ANY FURTHER




ANCHORING OF SHED



- EACH ANCHOR CONSISTS OF ONE NUT, BOLT, DYNABOLT AND STEEL ANGLE
- DRILL A 10mm HOLE INTO THE WALL SHEET
- DRILL A 10mm HOLE INTO THE CONCRETE (NOT INCLUDED IN KIT)




DOOR PANEL ASSEMBLY





FINAL CONSTRUCTION


CONNECT DOOR TO FRONT FRAME



NOTE: NUTS AND BOLTS (SUPPLIED) MAY BE USED INSTEAD OF POP RIVETS (SUPPLIED) BY SIMPLY ENLARGING THE HINGE HOLE SETS IN THE JAMB USING A 4MM DRILL BIT



FOR INTERNAL LOCKING
DOOR BOLT AND PAD PLATE CAN BE
RE-LOCATED TO INSIDE OF DOOR



NOTE: The two holes required to connect the padbolt hasp for each door have not been pre-punched, to allow for proper alignment. Position the hasp centrally over the padbolt shaft, and drill 3mm holes and secure with screws.